


Boiler onderdelenlijst model ELO0011/ETSS1-EU



	Engels	Nederlands
1.	PC plate	PC-plaat
2.	PET label	PET-etiket
3.	Light blocking bracket	Montagebeugel met licht
4.	Display board	Displaybord
5.	Body case	Behuizing
6.	Screw	Schroef
7.	Top cover	Bovendeksel
8.	Insulation	Isolatie
9.	Inner	Binnentank
10.	T-seal	T-afdichting
11.	Outlet nut (red)	Uitlaatmoer (rood)
12.	Silicone ring	Siliconen ring
13.	Transport cap (blue)	Transportdop (blauw)
14.	Transport cap (red)	Transportdop (rood)
15.	Inlet nut (blue)	Inlaatmoer (blauw)
16.	O-ring	O-ring
17.	O-ring	O-ring
18.	Adapter	Adapter
19.	Clamp	Klem
20.	Claw	Klauw
21.	Clip	Clip
22.	NTC	NTC weerstandsensor
23.	Flexible tube	Flexibele buis
24.	Bladder B	Bliester B
25.	Seal cup	Afdichtingsrand
26.	Venturi connector	Venturi (stromingkanaal) -connector
27.	Screw	Schroef
28.	O-ring	O-ring
29.	Screw	Schroef
30.	Bladder A	Bliester A
31.	Screw	Schroef
32.	Foot pad rubber	Stootmateriaal rubber
33.	Nut	Moer
34.	Silicone tube	Siliconen buis
35.	Clip	Clip
36.	Power socket	Stroomaansluiting
37.	Float switch	Vlotterschakelaar
38.	Thermostatic	Thermostaat
39.	Nut	Moer
40.	Screw	Schroef
41.	Inner bracket	Binnenbeugel
42.	PCB bracket	PCB beugel
43.	Power board	Stroombord
44.	Wire set	Draadset
45.	Gasket	Pakking
46.	Gasket	Pakking
47.	Bottom cover	Onderdeksel
48.	Heating tank	Verwarmingstank

